

The Kenton Pro-2000 MkII Editor requires Max or Max-Runtime (OsX or Windows) which you can download at <http://cycling74.com/downloads/>.

A help file (picture below) can be found in the "Menu" - besides the Presets.

Apart from the fact that i can't see any possibility of arranging destruction with this software, i want to point out that you are using it at your own risk.

Enjoy!

Kenton Pro-2000 MkII Editor

Chan	Pitchbend Range	Transpose	Depth	Cl
1	2	0	1	Modulo
Newsel	Fine Tune	Porta Contr	L Amount	F
Multi Trig	0	65	Portamento Ped	64
Gate Sv	Scale Amount	Porta Speed	Assign	LFO 1
Vol/Ov	0	98		

Chan	Pitchbend Range	Transpose	Depth	Cl
2	2	0	1	Modulo
Newsel	Fine Tune	Porta Contr	L Amount	F
Multi Trig	0	65	Portamento Ped	64
Gate Sv	Scale Amount	Porta Speed	Assign	LFO 2
Vol/Ov	0	98		

Chan	TransChan	ExpPort	Chan
3	1	D	4

Chan	Ctrl	Min	Max	Reset	L	Dpth	Cl	Armt	Assign	
X1	16	Gen Pur.	-64	63	-64	17	Gen Pur.	64	LFO 1	
X2	2	16	Gen Pur.	-64	63	-64	17	Gen Pur.	64	LFO 1
X3	3	16	Gen Pur.	-64	63	-64	17	Gen Pur.	64	LFO 1
X4	4	16	Gen Pur.	-64	63	-64	17	Gen Pur.	64	LFO 2
X5	5	16	Gen Pur.	-64	63	-64	17	Gen Pur.	64	LFO 2
X6	6	16	Gen Pur.	-64	63	-64	17	Gen Pur.	64	LFO 2

Chan	Ctrl	Min	Max	Reset	L	Dpth	Cl	Armt	Assign
AX	1-6	24							
L	LFO1	Speed	LFO1 WSho	LFO1 Sync Div					
F	Random	80	Random	rj	0				
O	LFO2	Speed	LFO2 WSho	LFO2 Sync Div					
	Random	80	Random	rj	0				

Menu	Clock Div	Clock Pol	Clock Cont.
EMU XM681X1 Mch Out	24	positive	Continue ignored

This Editor does not receive data from the Kenton Pro-2000 MkII. Therefore it has no Dump request.

When a (single) Preset is recalled in the software the settings will be dumped to the Kenton Pro-2000 MkII.

To save the settings inside the Kenton Pro-2000 MkII hardware please use the hardware-buttons.

To save all software-presets permanently click "Menu" and follow the instructions.

The file "KentonPro2k.maxpresets" will be loaded as the default preset file and needs to be in the same folder as the editor.

The other file located in the folder is "KentonProMIDI.maxpresets". This file keeps the MIDI-Prefs. When the (yellow) MIDI-Port address is changed the software will save the new address setting automatical.

Presets:
 Blue = saved preset
 Cyan = active preset
 Grey = empty preset

Recall = click
 Save Preset = Shift click

Presets

MIDI-Port

Menu

bohnes.de